
16121 Flight Path Dr. Brooksville, FL 34604 (352)593-5900

TIME DELAY SWITCH

Installation Instructions



This time delay switch will allow you to activate/deactivate a stage of nitrous as a function of time.


Use the small switches on the top of the timer to set the amount of delay (0.1 to 102.3 seconds).

If using an RPM switch, connect the yellow wire from the RPM switch to the green wire of the relays.

If using a pushbutton, connect it in place of the W.O.T. switch shown.

This time delay switch is set to activate a 2nd stage of nitrous after a delay of 1.1 seconds.

CAUTION! The time delay switch is only rated for 10 amps. Using the relay is a definite MUST!



Induction Solution 16121 Flight Path Dr. Brooksville Florida 34604 www.inductionsolutions.com

